NX30
Firmware Upgrade guide
(i-Launcher)

**Samsung Electronics.**

NX30 Firmware upgrade guide

● Easy Firmware upgrade: Please use i-Launcher program

(You can install "i-Launcher" program using installation CD)

● If you download Firmware from Samsung.com homepage directly,

→ refer to No.7(page 4)

※ **Information**

1) Use the full charged battery

2) Suggested memory card format before upgrade start

3) During the updating process:

Do not cut off the power / Do not remove the battery

→ It causes the cannot power-on or the severe damage

4) Finish upgrade: all menu will be reset

Firmware Upgrade method

1. You can connect the camera to your computer
**2. Opening "Samsung i-Launcher"**
  → select "Firmware Upgrade" menu
  * Automatically "Upgrade window" open
   if new firmware registered.


3. You can check precautions

4. Firmware download start

**5. Once the transfer is complete, click the Close button**

Firmware upgrade for a camera/camcorder ✕

Downloading the latest firmware has been finished.

After disconnecting the camera/camcorder from the PC, power on the device. For a compact camera or a camcorder, firmware upgrade resumes when the shutter button is pressed.

For an NX camera, "Body Firmware","Lens Firmware" should be selected in the firmware update menu of the device to start firmware upgrade.

For some camera models, rotate the zoom button to the left and hold it, and then press the Playback button to display the firmware update prompt. (WB35F, WB50F, WB1100F, WB2200F)

When firmware upgrade is over, the camera/camcorder shuts itself off. When powered on again, new firmware will be applied. If the battery level is low, firmware upgrade does not start. (Please do not remove the battery during firmware upgrade.)

✓ Close

**6. Terminate the USB cable connection**

7. Turn the camera on

※ **If you don't use i-Launcher but download Firmware from Samsung.com homepage directly → unzip "zip" file & copy firmware file to SD card**

**8. Select the MENU → Setting → Device Information**

📷	File Number	Series
🎥	Folder Type	Standard
	Format	
👤	**Device Information**	
⚙	Dual-band Mobile AP	2.4 GHz

MENU Back

9. Select Software Update → Body Firmware Update

MENU Back

Device Informat — Software Update
Software Updat — **Body Firmware** 🟢
Lens Firmware ○

Body Firmware	01.00
Lens Firmware	01.11
Mac Address	A0:21:95:5E:7F:03
Network certification number	603900002968

10. Update will start follow below sequence

Body Upgrade?

1.00 >1.10

Yes **No**

F/W Check 〉Update(1/2) 〉Update(2/2) 〉Update Finish

① Firmware version checking
  Press "Yes" → Upgrade start

Checking firmware...

F/W Check 〉Update(1/2) 〉Update(2/2) 〉Update Finish

② checking firmware file

**Firmware check complete.
Device will restart.**

F/W Check 〉Update(1/2) 〉Update(2/2) 〉Update Finish

③ Device will restart after checking firmware

**Updating(1/2)
Do not power off.**

F/W Check 〉Update(1/2) 〉Update(2/2) 〉Update Finish

④ after restart → updating start
※ Do not cut off the power
  Do not remove the battery

**Updating(2/2)
It will reboot in 1 minute.**

F/W Check 〉Update(1/2) 〉Update(2/2) 〉Update Finish

⑤ You can see the updating status
→After finish updating(2/2)
→Camera power-off & reboot
※ upgrade is not finished

Body Firmware update completed.

F/W Check 〉Update(1/2) 〉Update(2/2) 〉Update Finish

⑥ Finish upgrade
→ You can see "Firmware update completed" message
※ If your camera stop or power-off during upgrading
→ Please retry upgrade