

Contents

1. Product Specification

1-1 Specifications	1-1
1-2 Instructions on how to use the memory card	1-4
1-3 LCD monitor indicator	1-5
1-4 Camera Connection Diagram	1-6
1-5 Identification of features	1-7

2. Operation Instruction & Installation

2-1 Install	2-1
2-2 FAQ	2-3

3. Exploded View and Parts List

3-1 MAIN ASSEMBLY	3-1
3-2 BODY ASSEMBLY	3-2
3-3 CHAMBER ASSEMBLY	3-4
3-4 TOP COVER ASSEMBLY	3-6
3-5 FRONT COVER ASSEMBLY	3-8
3-6 BACK COVER ASSEMBLY	3-9
3-7 BARREL ASSEMBLY	3-10
3-8 PACKING ITEM	3-13

4. Firmware update

4-1 Product reset	4-1
4-2 Version check	4-2
4-3 Upgrade	4-3
4-4 Full upgrade	4-5
4-5 OIS Firmware	4-8

Contents

5. Adjustment

5-1 Basic guide for adjustment.....	5-1
5-2 OB Setting	5-3
5-3 Lens Shading	5-4
5-4 Shutter Close Time ADJ	5-5
5-5 CCD Gain ADJ	5-6
5-6 Flash ADJ	5-7
5-7 PUNT ADJ.....	5-8
5-8 B/T Level ADJ	5-10
5-9 CCD Defect ADJ.....	5-10
5-10 BackLash ADJ	5-11
5-11 Burning ADJ	5-11
5-12 IRIS adjustment.....	5-12
5-13 OIS Centering adjustment.....	5-13
5-15 Serial number writing process	5-14

6. Block Diagram

7. PCB Diagrams

7-1 Main PCB (TOP).....	7-1
7-2 Main PCB (Bottom).....	7-2
7-3 Top PCB (Top).....	7-3
7-4 Top PCB (Bottom).....	7-4
7-5 3 Combo PCB (Bottom).....	7-5

8. Schematic Diagrams

8-1 Main PCB-1.....	8-1
8-2 Main PCB-2.....	8-2
8-3 Main PCB-3.....	8-3
8-4 Main PCB-4.....	8-4



Contents

8-5 Main PCB-5.....	8-5
8-6 Main PCB-6.....	8-6
8-7 Main PCB-7.....	8-7
8-8 Main PCB-8.....	8-8
8-9 TOP PCB-1	8-9
8-10 TOP PCB-1	8-10
8-11 3 COMBO PCB-1	8-11

9. Disassembly and reassembly

9-1 Disassembly of main unit	9-1
9-2 Barrel disassembly	9-9

Memo